



RICCAR


PARTS BOOK

BAGLESS BROOM MODEL R60






KEY	PART NUMBER	DESCRIPTION
1	C669-0200	Suction Relief Valve Assembly
2	C669-0300	Motor Assembly
3	C669-0400	Motor Housing Latch Assembly
4	B669-0200	Dust Cup Base
5	A669-0100	Dust Cup Base Seal
6	B669-0513	Filter Cover
7	C669-0500	Dust Cup Assembly
8	C669-0600	Dust Cup Latch Assembly
9	B669-0600	Dust Cup Latch
10	A669-0200	Dust Cup Latch Spring
11	Not Available	Dust Cup
12	C669-0700	Dust Cup Internal Filter Holder Assembly
13	B669-0900	PC Board
14	C669-0900	Power Cord with Strain Relief
15	A669-0400	On/Off Switch
16	RF60	Filter Set



NOZZLE ASSEMBLY

RICCAR R60

KEY	PART NUMBER	DESCRIPTION
1	C669-3013	Floor Nozzle Assembly
2	B669-4000	Nozzle Release Button
3	B669-4100	Nozzle Neck
4	C669-3113	Rear Wheel Assembly
5	C669-3200	Front Wheel and Axle Set (2 each)
6	A669-0500	Squeegee
7	A669-0600	Nozzle Bumper
8	B669-3013	Nozzle Cover



HANDLE AND ACCESSORIES

RICCAR R60

KEY	PART NUMBER	DESCRIPTION
1	C669-0113	Handle Assembly
2	B669-0113	Cord Hook Black
3	B669-0300	Crevice Tool Holder
4	B669-0400	Crevice Tool
5	C669-3013	Floor Nozzle Assembly