



RICCAR

PARTS BOOK

SUPRAQUICK MODEL
RSQ1.6






MAIN BODY

Riccar Model RSQ1.6

KEY	PART NUMBER	DESCRIPTION
1	Not Available	Vacuum Housing (Left)
2	Not Available	Vacuum Housing (Right)
3	BB00071B	Gasket (2 Required)
4	BA00551B	Vacuum Housing (Front)
5	Not Available	Baffle
6	BF00051	V-Hook Tri Ring
7	Not Available	Round Mesh Screen
8	Not Available	Front Motor Mount
9	BB00031	Rear Mount
10	C345-0800B	Motor with Improved Mounts (Includes #8 and #9)
11	DB00011B	Switch
12	DG00011B	Power Cord
13	BD00261	Front Cover Clamp
14	Not Available	Mesh Screen
15	FA00011	Motor Filter
16	RSQ-6	Paper Bag (6 Pack)
17	BB00051	Hose Inlet Cover
18	Not Available	Wire Joints
19	FC00011	Strap
20	AA00551	Reusable Cloth Bag



ACCESSORIES

Riccar Model RSQ1 .6

KEY	PART NUMBER	DESCRIPTION
1	FB00081	Hose Assembly
2	BA00391B	Upholstery Tool With Brush
3	BA00411B	Dusting Brush
4	BA00371B	Crevice Tool
5	BA00401	Carpet Floor Tool
6	BA00381	Extension Wand
7	AA00551	Reusable Cloth Bag
8	BA00372	Mesh Bag
9	Included in Mini Vacuum Attachment Kit FB-05081	Hose Adapter
		Mini Blow Hose Assembly
		Mini Round Brush
		Mini Oval Brush
		Mini Straight Wand
		Mini Curve Wand
		Mini Crevice Tool
10	RSQ-6	Paper Bag (6 Pack)