


SIMPLICITY PARTS BOOK

Freedom Models


F3400 F3500 F3500C F3600 F3700 F3700.SAND F3700C

HANDLE AND BAG Simplicity Model F3400 F3500 F3500C F3600 F3700 SAND F3700C




HANDLE AND BAG Simplicity Model F3400 F3500 F3500C F3600 F3700 SAND F3700C

KEY	PART NUMBER	DESCRIPTION	KEY	PART NUMBER	DESCRIPTION
1	D431-3214	Handle Assembly Single Speed (F3400 F3500)	19	B211-6400	Bag Collar Seal
	D431-3100	One Speed Handle Assembly Commercial (F3500C)	20	B211-2314	Bag Collar Ring
	D431-3714	Two Speed Handle Assembly Household (F3600)	21	D211-3614	Bag Holder Assembly
	D431-3314	Two Speed Handle Assembly Household (F3700/F3700. SAND)	22	B211-1014B	Lower Bag Clip No Print (F3400/ F3500/F3600/F3700/ SAND)
	D431-3400	Two Speed Handle Assembly Commercial (F3700C)		B211-1914F	Lower Bag Clip Commercial Print (F3500C/F3700C)
2	C431-3614	Handle Grip	23	D211-6100	Cloth Bag Assembly
3	A732-8314	Screw #8 x 5/8"	24	B211-1204	Lower Bag Spring
4	A732-8414	Screw#8 x 7/16"	25	ULW-PLAIN.2	Paper Bag (Single Bulk)
5	A428-2014	One Speed Main Switch (F3400/F3500/F3500C)		SF-6	Paper Bag (6 Pack)
	A428-2200	Two Speed Main Switch (F3600/F3700/F3700.SAND/ F3700C)		THB-ULW	HEPA Bag (Single Bulk)
6	B123-0100	Wire Connector Medium		SFH-6	HEPA Bag (6 pack)
7	B431-3314C	Handle Back	26	D434-3143	Power Cord Assembly One Speed Household (F3400/ F3500)
8	B431-3714	Plastic Cord Hook Swivel (F3400/ F3500/F3600/F3700/ SAND)		D434-3414	Power Cord Assembly One Speed Commercial (F3500C)
	B384-0900	Metal Cord Hook (F3500C/F3700C)		D434-3643	Power Cord Assembly Two Speed Household (F3600)
9	B430-0200	Upper Cord Hook Spring (F3400/ F3500/F3600/F3700/ SAND)		D434-1800	Power Cord Assembly Household Hall Sensor (F3700/ F3700.SAND)
	B430-0200	Upper Cord Hook Spring (F3400/ F3500/F3600/F3700/ SAND)		D434-1900	Power Cord Assembly Commercial Hall Sensor (F3700C)
10	A430-0405	Upper Cord Hook Washer	27	A732-9206	Screw #5 Hi Lo Self Threading
11	A430-0205	Upper Cord Hook Screw			
12	B431-3504E	Steel Handle Tube			
13	A432-0705	Screw #10 32 x 1.625			
14	B430-1205	Metal Lower Cord Hook			
15	B431-2914E	Handle Tube Bracket			
16	A432-0805	Hex Nut			
17	D431-3014	Lower Handle Upper Fan Housing (F3500C/F3700C)			
	D431-0200	Lower Handle Upper Fan Housing (F3400/ F3500/ F3600/F3700/SAND)			
18	B211-3614	Bag Holder			



NOZZLE**Simplicity Model F3400 F3500 F3500C F3600 F3700 SAND F3700C**

KEY	PART NUMBER	DESCRIPTION	KEY	PART NUMBER	DESCRIPTION
1	B018-0315C	Headlamp Lens	19	B016-1230	Upright Stop
2	Not Available	Nozzle Cover (F3400 F3500 F3500C F3600 F3700 F3700SAND)	20	B015-0400	Foam ULW Basetray
	D017-2114	Black Replacement Nozzle (F3400, F3500, F3500C, F3600)	21	B010-0001E	Base Tray Wheel Axle
	D017-2214	Black Replacement Nozzle Assembly with Hall Sensor Lens (F3700,F3700.SAND, F3700.2SAND)	22	B010-0614	Base Tray Small Wheel
3	B029-0314	Furniture Guard	23	D012-2800	Wood Agitator (F3400/ F3500/F3500C/F3600)
4	D123-3814	Fan Duct Cover With Seal		D013-0500	Steel Agitator Nylon Strips ((F3700/F3700.SAND/F3700C)
5	C121-0000	Motor Seal Kit	24	B015-3114	Raw Base Plate (F3400/ F3500/3500C/F3600/ F3700/F3700.SAND/ F3700C)
6	B123-3614	Lower Fan Housing			
7	B123-3000B	Motor Fan	25	B015-3000B	Baseplate Squeegee
8	A732-9305	Behind Fan Washer (Ametek Motor)	26	B370-1700B	Base Plate Axle
	A733-3300	Behind Fan Washer (TEK Motor)	27	B370-1843	Base Plate Wheel
9	A733-2200	Washer (TEK Motor)	28	D015-2914	Base Plate with Wheels and Squeegee (F3700/ F3700.SAND/F3700C)
10	A732-3000	E-Clip .250" For Motor Shaft Flat Belt (F3400/F3500/F3500C/ F3600)			
11	D113-1500	Motor Assembly Straight Shaft (F3400/F3500/F3500C/F3600	29	A732-2500	Combination Screw M4 x 12
	D113-1400	Motor Assembly Pulley Shaft (F3700/F3700.SAND/F3700C)	30	B034-0100	Strain Relief Washer
12	A732-8314	Screw Hi Lo #8 x 5/8	31	A732-7300	Screw #4 X 5/16
13	B014-0814B	Flat Belt Bulk Single(F3400/ F3500/F3500C/F3600)	32	B317-0000K	PC Board (F3600)
	ULW-B2	Flat Belt 2 Pack (F3400/F3500/ F3500C/F3600)		B317-1000BK	Hall Sensor PC Board (F3700/F3700.SAND/ F3700C)
	B014-1200	V Belt (F3700/F3700.SAND/ F3700C)	33	A018-1300	Plastic Dowel Pin(F3700/ F3700.SAND/F3700C)
14	A350-0000	Light Bulb	34	A732-8414	Screw Hi/Lo #8 7/16"
15	A018-0900	Light Socket	35	D375-1400	Hall Sensor Assembly (F3700, F3700.SAND, F3700C)
16	D350-6631	Large Rear Wheel and Axle	36	A028-0114B	Circuit Breaker 5 Amp (F3400, F3500, F3500C, F3600
17	D016-1114	Base Tray Assembly with Plastic Upright Stop			
18	B016-1914	Basetray Plug Non Hall Sensor Models (F3400 F3500 F3500C F3600)	37	A018-1414	Plug For Circuit Breaker Hole (F3700, F3700.SAND, F3700C)
			38	B433-0341	Lead Wire Yellow (F3400, F3600)



KEY	PART NUMBER	DESCRIPTION
1	A375-0100	1/4 - 28 Locking Hex Nut
2	B013-1600	Metal End Cap
3	A733-1810	Screw Pulley End 80mm
4	B475-1900	Retainer Ring
5	B375-3900	Felt Seal
6	A375-0200	Bearing
7	C013-0800	Pulley Non-Clamping Design for Poly V Belt
	B013-1400	Pulley Clamping Design for Poly V Belt
8	B013-1000	Short Brush Strip Nylon
	B013-0301B	Short Brush Strip White
	B013-0400	Short Brush Strip Natural
9	B475-0400B	Long Brush Strip Nylon
	B013-0401B	Long Brush Strip White
	B013-0300	Long Brush Strip Natural
10	C013-0900	Agitator Bearing Holder With Edge Brushes Non-Clamping
	B013-1500	Agitator Bearing Holder With Edge Brushes Clamping Design
11	A733-1800	Screw Non-Pulley End 40mm
12	D013-0500	Steel Agitator Assembly Clamping Design Tested