



SIMPLICITY PARTS BOOK

**JILL.3 JILL.4 JILL.6 JILL.8 JILL.10 JILL.12
MODELS**



MAIN BODY PARTS


Simplicity Model JILL.3 And Above



MAIN BODY PARTS

Simplicity Model JILL.3 And Above

KEY	PART NUMBER	DESCRIPTION
1	B361-3300	Suction Inlet Seal
2	B361-4200	Bag Inlet Seal
3	B361-4100	Cord Rewind Pedal
4	B361-4000	On/Off Pedal
5	C361-18PK	Dust Cover Lid Assembly Pink (JILL.3 JILL.4 JILL.6 JILL.10)
	Not Available	Dust Cover Lid Assembly White (JILL.12)
6	B362-4000	Spring for On/Off Pedal &
7	C361-1600	On/Off Switch Assembly
8	C360-1000	FBI Assembly
9	B361-4300	Secondary Filter Holder
10	SF-I4.3	HEPA & Secondary Filter Package
11	B361-4500 Not Available	Motor Cover Seal
12	B361-4600	Dust Compartment Seal
13	SZH-6	HEPA Bag Package
14	C361-1100	Bag Holder
15	C361-1700	Motor Upper Housing & Seal
16	D361-1500	Cord Reel Assembly
17	B361-4400	Cord Outlet Cover
18	C361-1300	Motor Assembly
19	C361-1400	Bottom Housing Assembly
20	B360-0600	Furniture Guard
21	C361-2200	Rear Wheel Assembly
22	C361-0600	Caster Wheel Assembly
23	C361-0800	Dust Cover Latch & Spring Assy
24	B361-5300	Hose Inlet



HOSE, WAND, ACCESSORIES**Simplicity Model JILL.3 And Above**

KEY	PART NUMBER	DESCRIPTION
1	B361-2700	Cleaning Tools Holder
2	C361-0700	Hose Assembly
3	B361-2500	Wand
Not Shown	B361-5400	Wand Docking Clip
4	B361-2900	Crevice Tool
5	B361-3000	Upholstery Tool
6	B361-2800	Dusting Brush
7	HVST Not Available	Rug/Floor Tool (JILL.3 JILL.4)
	C361-2600	Combo Rug Floor Tool (All Versions)
8	HFI-B	Floor It Hard Surface Tool (Opinional For All Versions)
Not Shown	MFP-3	White Microfiber Pad 3pk
	FLOORTOOL-PAD	Micropad For HFI Tool Bulk