


Simplicity[®]


VACUUM

Parts Book

S65, S65D, S65P,

S65S






ASSEMBLIES AND TOOLS

Simplicity S65, S65D, S65P, S65S

KEY	PART NUMBER	DESCRIPTION
1	B240-0100	Main Body (Does not include dust cup, filter cover, or filter)
2	B240-0200	Wand
3	B240-0500	Angle Adapter (S65, S65P)
4	B240-0300	Upholstery Tool (S65, S65D, S65P)
5	C240-0300	Pet Tool Turbo Brush (S65, S65D, S65P)
6	B240-0400	Crevice/Dusting Tool Combo(All Models)
7	C240-1000	Bare Floor Soft Nozzle (S65, S65P)
8	C240-0600	Carper/Bare Floor Nozzle (All Models)
9	B240-0700	Wall Mount w/ anchors and screws
10A	B240-0600	Storage/Charging Station (S65, S65D, S65S)
10B	B240-0610	Storage Dual Charging Station (S65P)
11	C240-0100	Battery
12	C240-0900	Battery Charger Cord

DUST CUP ASSEMBLY


Simplicity S65, S65D, S65P, S65S




KEY	PART NUMBER	DESCRIPTION
1	C240-0200	Filter Top Assembly
2	SF65	Filter
3	C240-0800	Dust Cup Assembly
4	C240-1100	Dustcup Filter Assembly S65

BARE FLOOR NOZZLE ASSEMBLY

Simplicity Model S65, S65P



KEY	PART NUMBER	DESCRIPTION
1	C240-0500	Nozzle Neck Button and Spring
2	B240-0800	Bare Floor Soft Brushroll Left Cover
3	C240-0400	Bare Floor Soft Brushroll Assembly (Blue)
4	B240-1000	Nozzle Felt Strips (Set)
5	C240-1000	Bare Floor Soft Nozzle Assembly



KEY	PART NUMBER	DESCRIPTION
1	C240-0500	Nozzle Neck Button and Spring
2	C240-0700	Carpet/Floor Brushroll Assembly
3	B240-1100	Nozzle Felt Strips (Set)
4	C240-0600	Carpet/Floor Nozzle Assembly